

Rain sensor Art.-No.: RW 95

Operationsmanual

1 Safety instructions

Electrical equipment may only be installed and fitted by electrically skilled persons.

Failure to observe the instructions may cause damage to the device and result in fire and other hazards.

Danger of electric shock. Risk of injury from automatic movement of blinds/shutters. Always disconnect before carrying out work on the devise or load.


Danger of electric shock. Insulate unused wires.

Risk of injury from hot surfaces. The integrated heater can cause the sensor surface to reach high temperatures. Do not touch the sensor surface.

The sensor surface is delicate; protect it when handling the device. Clean the sensor surface only with mild cleaning agents. Sensor surface can be damaged.

These instructions are an integral part of the product, and must remain with the end customer.

2 Device components



- (1) Mounting bracket
- (2) Sensor surface
- (3) Power cable
- (4) Control cable

3 Function

Intended use

- Sensor for detection and evaluation of precipitation
- In connection with blind/shutter controllers, enables, e.g. the retraction of awnings when it begins to rain.
- Surface-mounted device for outdoor installation



Product characteristics

- Serpentine-shaped sensor surface detects wetting due to precipitation.
- Change-over relay remains switched on until the sensor is dry again. For at least 10 minutes.
- Integrated heater speeds up the drying of the sensor surface and melts snow and ice.

4 Information for electrically skilled persons

4.1 Fitting and electrical connection

Fitting the device

The 110° mounting bracket ensures an optimal mounting position at all times for mounting on vertical walls. The mounting bracket can be installed on a mast using the supplied clamp.

Mount the precipitation sensor in such a way that rain can reach it in an unobstructed manner.

Connecting the device



DANGER!


Electrical shock when live parts are touched.

Electrical shocks can be fatal.

Before working on the device, disconnect all the corresponding miniature circuit breakers. Cover up live parts in the working environment.

Connected to the precipitation sensor are two PVC hose lines with numbered wires. Control cable (4)

Wire 1: NC contact
Wire 2: centre contact
Wire 3: NO contact



picture 2: Example for connection of precipitation sensor to blind/shutter controller (6)

- Connect mains cable (3) and control cable (4) of the precipitation sensor (5) as shown in the connection example (picture 2). Wire 3 of the control cable should be connected to the outer conductor so that no voltage is present on the free wire 1.
- i The change-over contact can be used for either 230 V or for safety extra-low voltage.



AC 230 V ~

50 / 60 Hz

5 Appendix

5.1 Technical data

Rated voltage
Mains frequency
Power consumption
Current consumption
Ambient temperature
Safety class
Protection rating
Breaking capacity
Switching current for AC 250V~

Contact type Dimensions WxHxD

Weight

Connection cable Power cable Control cable

Run-on time

max. 4.5 W (incl. additional heating)
approx. 15 mA (with preheating)
-30 ... +70 °C
II
IP 65
max. 1500 W (ohmic)

μ contact, potential-free change-over contact 130×90×90 mm (incl. mounting bracket) approx. 600 g (incl. mounting bracket)

JZ-600, 2×0.75 mm², 3 m JZ-600, 3×0.75 mm², 3 m

approx. 10 min

5.2 Warranty

We reserve the right to make technical and formal changes to the product in the interest of technical progress.

We provide a warranty as provided for by law.

Please send the unit postage-free with a description of the defect to our central customer service office:

ALBRECHT JUNG GMBH & CO. KG

Service Center Kupferstr. 17-19 D-44532 Lünen

Service-Line: +49 (0) 23 55 . 80 65 51 Telefax: +49 (0) 23 55 . 80 61 89

mail.vka@jung.de

General equipment

Service-Line: +49 (0) 23 55 . 80 65 55 Telefax: +49 (0) 23 55 . 80 62 55 mail.vkm@jung.de

KNX equipment

Service-Line: +49 (0) 23 55 . 80 65 56 Telefax: +49 (0) 23 55 . 80 62 55

mail.vkm@jung.de

The CE symbol is a free trade symbol, which is solely intended for the authorities and does not guarantee any properties.

ALBRECHT JUNG GMBH & CO. KG

Volmestraße 1

D-58579 Schalksmühle

Telefon: +49.23 55.8 06-0 Telefax: +49.23 55.8 06-1 89 E-mail: mail.info@jung.de Internet: www.jung.de

www.jung-katalog.de